

# Hamlet

## SMART DVD MAKER USB 2.0 Analogue Video Capture



## USER MANUAL

XDVDMK4

[www.hamletcom.com](http://www.hamletcom.com)

# Contents

<b>1. Hardware Installation</b> .....	<b>3</b>
1.1 Package Contents.....	3
1.2 System Requirements.....	3
1.3 Hardware Installation .....	3
<b>2. Driver Installation</b> .....	<b>4</b>
<b>3. FAQ (Frequently Asked Questions)</b> .....	<b>5</b>
3.1 How to check if the driver has been installed successfully or not.....	5
3.2 How to uninstall device driver .....	5

Dear Customer,

thanks for choosing an Hamlet product. Please carefully follow the instructions for its use and maintenance and, once this item has run its life span, we kindly ask You to dispose of it in an environmentally friendly way, by putting it in the separate bins for electrical/electronic waste, or to bring it back to your retailer who will collect it for free.



We inform You this product is manufactured with materials and components in compliance with ROHS Directive 2011/65/EU, with WEEE Directive 2002/96/CE, 2003/108/CE Italian Legislative Decree 2005/151 and EMC Directive 2014/30/EU for the following standards:

EN 55032: 2015, EN 61000-3-2: 2014, EN 61000-3-3: 2013, AS/NZS CIS32: 2015,  
EN 55024: 2010 + A1: 2015, IEC 61000-4-2: 2008, IEC 61000-4-3: 2006 + A1: 2007 + A2: 2010,  
IEC 61000-4-4: 2012, IEC 61000-4-5: 2014, IEC 61000-4-6: 2013, IEC 61000-4-8: 2009,  
IEC 61000-4-11: 2004.



The complete CE declaration of conformity of the product can be obtained by contacting Hamlet at [info@hamletcom.com](mailto:info@hamletcom.com).

Visit [www.hamletcom.com](http://www.hamletcom.com) for complete information on all Hamlet products and to access downloads and technical support.

Imported by: CARECA ITALIA SPA - Scandiano (RE) . Italy.

## Trademarks and Changes

All trademarks and company names mentioned in this manual are used for description purpose only and remain property of their respective owners.

The material in this document is for information only and subject to change without notice. Specifications and appearance of the product are subject to change without prior notice.

# 1. Hardware Installation

## 1.1 Package Contents

Unpack your Smart DVD Maker package and make sure that all items are included. The following items should be included in your package:

- Smart DVD Maker device
- Audio/Video multi-cable
- External USB cable
- Quick Installation Guide
- Installation DVD-ROM with driver, user manual and CyberLink PowerDirector 15 software


## 1.2 System Requirements

- Pentium 4 3.0GHz or above
- 1 GB RAM of system memory or above
- One available USB 2.0 port
- Graphics card (must support Microsoft DirectX 9.0c or above)
- Sound card (AC97 compatible)
- 2 GB free HDD space
- DVD-ROM drive
- Microsoft Windows 7, 8 and 10

## 1.3 Hardware Installation

Please follow the steps shown below for installation of your Smart DVD Maker.

1. Connect the Audio/Video input cable into the Smart DVD Maker connector.
2. Plug Smart DVD Maker dongle into the USB 2.0 port of your system.
3. Insert the Installation DVD into your computer and follow the setup wizard for driver and software installation.



## 2. Driver Installation

The Smart DVD Maker package comes with complete Windows software utilities. These utilities can be found on the CD-ROM in this package. During installation, it is highly recommended to disable any sub-programs. These include applications such as antivirus software and system monitoring applications.

1. Insert the installation DVD into the DVD drive.  
The autorun page will appear as image. Please choose **“Quick Installation”**.  
Note: Your Smart DVD Maker device must be plugged into the USB 2.0 port before installation.



2. In the **“Quick Installation”** window you can also select the installation of the additional software. The following steps show only the driver installation.



3. Press **“Start”** to install the driver and/or software.




4. When driver installation is complete, click **“OK”**.



### 3. FAQ (Frequently Asked Questions)

#### 3.1 How to check if the driver has been installed successfully or not


Open “Control Panel” window and click on “Device Manager”. Click on the arrow icon next to “Sound, video and game controllers” item to expand the device list. Smart DVD Maker will appear as “USB Capture Device”.




#### 3.2 How to uninstall device driver

Please follow below steps to remove the device driver.

1. Insert the installation DVD into the DVD drive.  
The autorun page will appear as image.  
Please choose “Quick Uninstallation”.




2. In the “Quick Uninstallation” window select the “Driver uninstallation” option and press the “Uninstall” button to proceed.



3. Press **“OK”** to uninstall the Smart DVD Maker driver.



4. Click **“OK”**.



5. Once uninstallation is complete, press **“Finish”** to exit and restart the computer.

